



# SIGN IN

الدخول لمتصفح google chrome وتسجيل ip  
الراوتر بالبحث 192.168.1.1

DSL-N16

Sign in with your ASUS router account

admin

.....

Sign in

Firmware Version: 1.1.2.3\_224 SSID: Asus2010



Quick Internet Setup

General



Network Map



Guest Network



Traffic Manager



Parental Controls

Advanced Settings



Wireless



LAN



WAN



IPv6



VPN



Firewall



Internet Status: **Connected**  
WAN IP: 10.236.19.96  
DDNS: [GO](#)



ASUS DSL-N16  
Security level:

**WPA2-Personal**



Clients: **2**

### System Status

2.4GHz

Status

Wireless name(SSID)

Asus2010

Authentication Method

WPA2-Personal

WPA Encryption

AES

WPA-PSK key

.....

Apply

LAN IP

192.168.1.1

PIN code

02145006

LAN MAC address

A8:5E:45:70:81:FC

Wireless MAC address

A8:5E:45:70:81:FC

 Skip Setup Wizard

Quick Internet Setup

1 Check Connection

2 Internet Setup

3 Router Setup

PPPoE

Transfer Mode: **ADSL WAN (ATM)**, WAN Connection Type: **PPPoE**, VPI/VCI: **8/35, LLC**

Please key in the user name/password that your Internet Service Provider (ISP) has provided and click Next.

Username

2

@waves.sy

@waves.sy

Password

3

.....

Show password

\*\*\*\*\*wg

Notice (specifically for Germany ISP NetCologne):

Bitte geben Sie diese Zugangsdaten in folgendem Format ein.

nc-**username**@netcologne.de

Special Requirement from ISP ( IPTV Service )

Manual Setting

Next

4



Skip Setup Wizard

Quick Internet Setup

1 Check Connection

2 Internet Setup

3 Router Setup

Wireless Setting

Assign a unique name or SSID (Service Set Identifier) to help identify your wireless network.

2.4GHz - Security

Network Name (SSID)

Asus2010

Network Key

.....

Enter a network key between 8 and 63 characters(letters, numbers or a combination) or 64 hex digits. The default wireless security setting is WPA2-Personal AES. If you do not want to set the network security, leave the security key field blank, but this exposes your network to unauthorized access.

Next

5  
username

6

password

7